



**Note**

1. For debug and test purpose, idtsmu-cdev can export custom functions to user space through files under /sys/class/idtsmu/idtsmu[x]. For Example, idtsmu-cdev is currently exporting scsr\_show\_regs, which can be read to show SCSR register content by page.